


Solar Man Robot

Components list is on PAGE 2.


1




Assemble right arm



Assemble left arm



2




Back


Front

Back

Please note to verify front and back, the holes in red rectangle are for this assembling step.




Install left leg




Install right leg


3



Firstly as picture shown, assemble the top of leg to the shaft of back cover.




Then fix motor and both legs.




Follow the picture, get the motor wire through out of the hole

4




As picture shown, install the right arm to the motor shaft.



Install the left arm the same as right arm.

5



Install the front cover.

